


# Bluetooth Talking Speaker NFC

**Model : DBoom** by [musemini.com](http://musemini.com)




**(USER MANUAL)**

The DBoom wireless Bluetooth Speakerphone turns any mobile device into a portable sound system with high definition sound and a built in mic for hands-free calling.

**Includes:**

- 1×DBoom Bluetooth Speakerphone
- 1×Carrying Pouch
- 2×Line-In/Line-Out Audio Cable
- 1×Micro USB Charging Cable



## **Pairing Your Device with the DBoom**

### **Standard Pairing**

1. Move the Power switch to “On” .The DBoom will say “Power On” once the power is on.
2. On your portable device, turn Bluetooth on, search for Bluetooth devices, and select “DBoom” .
3. If you are prompted to enter a password to Complete pairing ,enter 0000.
4. DBoom will connect to your device and be ready for use.

### **NFC Pairing**

If your device supports Near Field Communication technology (NFC),you can quickly pair your phone By following these instructions:

1. Move the Power switch to “On” .The DBoom will say , “Power On” ...[ pause]...Pairing” .
2. Hold your device to the top right corner of the back of the DBoom Speaker.
3. A prompt will appear on your device asking if your want to connect with the DBoom-select “ OK ” or “ Yes ” .
4. The DBoom will connect to your device and be ready fo use.

### **Note:**

Once you have completed the initial pairing process,  
Your mobile device will automatically search for and  
Connect to the DBoom when Bluetooth is turned on and the  
DBoom is in range. To connect to other Bluetooth devices you must

first turn off the DBoom or disconnect it from Your mobile device through your device's Bluetooth settings.

### **Calling with the Bluetooth Function**

1. Pair your mobile device with the DBoom as described above.
2. When an incoming call is detected, the DBoom will switch to speakerphone mode. Your handset will ring as normal while the DBoom beeps.
3. To answer a call, press the answer call button on the DBoom one time or answer the call on your handset as you normally would. Then use the DBoom as your speakerphone.
4. To end a call, press the end call button on the DBoom one time or end the call on your handset as you normally would.
5. To reject an incoming call you must do so on your handset as you normally would.

Note: If the DBoom is moved out of range or runs out of power and drops the connection to your portable device, you will need to recharge or move the DBoom closer to your portable device and reestablish the Bluetooth connection.

### **Playing Music with the Line-In Connection**

1. Move the Power switch to the "Off" position.
2. Plug the provided Line-In/Line- Out audio cable into the

DBoom Line-In Port then into your mobile device.

3. Move the Power switch to the “On” position.
4. You are now ready to play music with the DBoom speaker.

### **Using the Line-Out Connection**

You can use the DBoom built-in Line-Out port to connect another speaker to the DBoom.

1. Plug the provided Line-In/Line-Out audio cable into the DBoom Line-Out Port then into the additional speaker’s Line-In port
2. Turn both speakers on .
3. Connect your portable media device to DBoom by Bluetooth or by Line-In as described above to play music and make/answer calls.

### **Specifications**

1. Dual Speaker: D45mm(130HZ-20KHZ), 4Ω, 3W.
2. Double Bass Mode: D 45MM
3. Lithium Battery Input: 2000mAh,(DC 5V)
4. SNR: 90±3db
5. Bluetooth Version: 3.0, effective range: ≤10m
6. Charging Time: 4hours, Playing time:6-8hours
7. Dimension: 192.4 \*65\*78.7mm
8. Material : ABS Plastic + Metal Grill
9. Weight: 460g
- 10.

## **Charging the Battery**

1. Confirm the power is off.
2. Plug the provided USB charging cable into the speaker and an active computer USB port or a USB AC Adapter that is plugged into an active wall outlet.
3. Charging Time: 6 Hours.

**IF YOU HAVE ANY ISSUES PAIRING PLEASE CONTACT US AT**

**<http://www.musemini.com>**

**[CS@MUSEMINI.COM](mailto:CS@MUSEMINI.COM)**

**COMPANY VOICEMAIL: 866.548.6661**